



Tallon Mini Socket - Truck: Installation Instructions

Step 1: Select a spare switch blank in the dash or coaming of your truck and press out the blank plate.

Step 2: If the dash or coaming material is flexible, position the strengthening washer plate at the rear of the switch aperture.

Step 3: Insert the Mini Socket threaded barrel, making sure that the Tallon Logo is the correct way up.

Step 4: Take the locking nut and carefully start it on the threads of the Mini Socket barrel.

Step 5: Tighten the nut. Avoid cross-threading it as this will affect the unit's performance.

Step 6: To mount an accessory, insert your Stainless Tallon RAM Connector at a 45° downward angle; level the connector when fully inserted then pull firmly outwards. Press down on the Tallon Locking Tab to lock in place.

Enjoy the use of your Tallon Mini Socket! See the TallonTV Channel on YouTube for video demonstrations.

